

SYSTEM USER MSNUAL

HD1U-4860G-FIFO Embedded Power System



HUADA

Shenzhen Lonos Huada Power system company

SKYPE: Allen.Fisher | TEL: +86-755-21084387 | MOBILE | WECHAT | WHATSAPP: +86-13713988862

Address: building E, Yongda Science Park, Tianyang Road, Songgang town, Bao'an District, Shenzhen, China

Website: www.nxups.com

Email: allenfisher@nxups.com

High-performance high-reliability power products -48V power communications systems

Input:90~290Vac;Output: 42~58Vdc



Application

- Small Exchange
- Access Network
- Transmission Equip
- Satellite Comm Ground Station
- Microwave Comm Station

◆ *Feature*

- ◆ The rectifier module adopts active power factor compensation technology, with a power factor value of 0.99
- ◆ The normal working range of AC input voltage is as wide as 90-290V。
- ◆ The rectifier module adopts full bridge soft switching technology, with a maximum efficiency of over 92%.
- ◆ Comprehensive battery management. Equipped with load discharge and battery low voltage protection (LVLD+LVBD) and secondary discharge functions, it can achieve temperature compensation, automatic float charging control, automatic voltage regulation, battery capacity calculation, online battery testing and other functions.
- ◆ The rectifier module adopts non-destructive hot swapping technology, which is plug and play, and the replacement time is less than 1 minute.
- ◆ Networked design, providing multiple communication interfaces (such as RS485 and dry contacts), flexible networking, capable of limited local and remote monitoring, and unmanned.
- ◆ A comprehensive lightning protection design for both AC and DC sides, suitable for areas with frequent thunderstorms.
- ◆ Complete fault protection and fault alarm functions.
- ◆ Full frontal operation and maintenance, can be installed against the wall, effectively saving space.
- ◆ Safe and reliable. The system design fully complies with safety standards EN60950 and GB4943






Preface

Welcome to use the embedded power supply system developed and produced by our company. The system consists of a distribution unit, monitoring module, and rectifier module. The overall performance is stable and practical, and it can be operated by backend software.

Statement

1. The specification sheet provides a detailed description of the performance of the embedded power system. Before performing any operations on the power system, users are advised to carefully read this specification sheet and comply with relevant industry safety regulations. Our company is not responsible for product damage caused by improper operation or exceeding the usage conditions specified in this specification.
2. Our company has the right to modify the content of the manual without notifying the customer.

Safety Instruction

	The AC input line is a high-voltage working line, and the operation process must ensure that the AC input is powered off. Temporary prohibition signs should be added to switches that are not allowed to be used during the operation process.
	The contact points of AC line terminals and other unnecessary exposed areas should be fully insulated.
	Before powering on, it must be grounded.
	The module has a hot swappable function, but it must be ensured that the module panel indicator lights are all off before inserting the module
	High voltage and AC power operations are strictly prohibited in thunderstorm weather

Naming rules

HD1U-4860G-FIFO

S-Standard power system, 48-48V output, 60-60A output, B-rectifier version(option A,B,BH)

H-high efficiency(96%), 1U-1U height, FIFO-Front Input and Front Output

Index

Chapter 1 System Instruction	4
1.1 Configuration	4
1.2 Technical performance	4
1.2.1 Basic working principle	4
1.2.2 performance	4
1.3 Installation	7
1.3.1 Electrical connection between the main box and the outside	7
1.3.2 Installation inspection	8
1.4 Installation instructions for monitoring module and rectification module	8
Chapter 2 Monitor MOdulet	10
2.1 Appearance	10
2.2 System composition	10
2.3. Functions	10
2.4. Installation	20
2.5. Maintainece	21
Chapter 3 Rectifier Module	22
3.1 Appearance	22
3.2 Functions	22
3.2.1 characteristic	22
3.2.2 Protection function	22
3.3 Requirements for the working environment	23
3.4 Explanation and maintenance	23
3.4.1 panel	23
3.4.2 Alarm signal indication	23
3.4.3 Precautions for the use and maintenance	24
Chapter 4 Safety precautions for use	25
Chapter 5 Packaging, transportation, and storage	25
Chapter 6 Waranttye	26
Chapter 7 Relevant standards cited and referenced	26
Chapter 8 System working principle diagram	27

Chapter 1 System Instruction

1.1 Configuration

Our standard embedded systems mainly include several models and configurations as shown in the table below. (For non-standard products, the actual product shall prevail)

Configuration						
Module sys model	G Monitor	E Monitor	4830BH Rectifier	4820BH Rectifier	4815BH Rectifier	4810BH Rectifier
HD1U-4860G-FI FO	1		1-2	Optional	Optional	Optional

Distribution			
Dist sys mode	Battery	Secondary power off	Main power off
HD1U-4860G-FI FO	1-way output terminals	4-way output terminals	No

1.2 Technical Performance

Embedded systems are suitable for small programmable switches, access networks, transmission equipment, mobile communication, satellite communication ground stations, microwave communication power supply, and can also be used for power supply of other communication equipment.

1.2.1 Basic Working Principle

Under normal circumstances, various parameters of the rectifier module and distribution unit are controlled by the monitoring module and operate according to their predetermined parameters or user commands. If there is a mains power failure, the system will be powered by the battery. As the battery discharges, the voltage at the battery end begins to decrease. When the battery voltage drops below the 46V upper computer (configurable) battery low voltage alarm point, the monitoring module reports an alarm signal and directly turns off the load output, causing the entire machine to not work. When the external power supply is restored, the system returns to normal working state (the above monitoring data is the system default value, which can be reset by the user). If the working environment temperature is $\geq 55\text{ }^{\circ}\text{C}$, the power system will need to reduce its power output.

1.2.2 Performance

※ Common performance indicators for embedded systems

Input					
Parameter	Min	Typical	Max	Unit	Note
Input Volt Range	90	220	280	Vac	
Input Volt Frequency	45	50	65	Hz	
PF	0.98				

Output					
Parameter	Min	Typical	Max	Unit	Note

Output Volt Range	42	53.5	58	Vdc	
Output Curr Range	0		60	A	176~280VAC
	0		30	A	90~175VAC
Ripple(Peak)			200	mv	
Efficiency	≥95	96		%	220Vac
	≥92			%	110Vac
stabilization accuracy			≤±1	%	
Load regulation			≤±1	%	
Source Regulation			≤±1	%	

Insulation level		
Parameter	Standard requirements	Note
Input-Output	3000Vdc/10mA//1min	
I(nput--Shell	2500Vdc/10mA//1min	
Output-Shell	700Vdc/10mA//1min	
Insulation resistance	Under normal atmospheric pressure, with a relative humidity of 90% and a test voltage of 500V DC, the insulation resistance of the power supply input to output, input to ground, and output to ground shall not be less than 10M Ω. Leakage Current is ≤3.5 mA	

Enviroment					
Parameter	Min	Typical	Max	Unit	Note
Working Temp	-25		55	°C	Can operate normally under full load conditions at an ambient temperature of 55 °C, with a linear reduction of 2.0%/°C from+55 to+65 °C. Note 1
Storage Temp	-40		80	°C	
Humidity	10		90	%	Relative humidity, non Condensing
Air Pressure	70		106	KPa	
Altitude	0		3000	m	
Cooling Function	Forced air cooling, with forward air and rear air outlet. The fan is located in the front panel and has temperature control and speed regulation function.				

Protection						
Parameter	Unit	Yes/No	Min	Typical	Max	Recovery type
In Over-Volt Alarm	Vac	Yes	285	295	305	Recovery difference of 10 ± 5V
In under-Volt Alarm	Vac	Yes	85	90	95	
In Over-Volt Protection	Vac	Yes	300		315	Recovery difference of 10±5V
In under-Volt Prot	Vac	Yes	75		85	


Out Over-Volt Alarm	V	Yes	58		59	Recovery difference of 1V
Out Under-Volt Alarm	V	Yes	46.5	47	47.5	Recovery difference of 1V
Out over-Volt Prot	V	Yes	59		60	Can not auto recovery
Batt shunt prot	V	Yes	42.5	43	43.5	Recovery difference of 2.5-3V
Envi Hi Temp Alarm	°C	Yes	45	50	55	Recovery difference of 3°C
Envi Low Temp Alarm	°C	Yes	-15	-10	-5	
Short Protection	A	Yes	Can be short circuited for a long time; After detecting a short circuit and burping for 5 minutes, if the module output still has a short circuit, turn off the machine			

※ Different performance indicators for embedded systems

Input and Output					
Type sys mode	Input Current	Max	Output current		
			170~290VAC	151~175VAC	90~150VAC
HD1U-4860G-FI FO	20A		60A	22A	22A

Mechanical					
Type sys mode	Weight (KG)		Dimension(mm)		
	With module	Without Module	W	D	H
HD1U-4860G-FI FO	≤8	≤4	482.6	270	43.6

Dimension(mm)




1.3 System Installation

When the embedded system is packaged and transported, the monitoring module and all rectifier modules have been installed on the system main box (except for special requirements).



The installation dimensions of the system are all standard 19 inches. It is recommended that two people cooperate during installation, one person supports the frame, and the other person uses tools such as screwdrivers to fix it to the customer's cabinet using the holes of the frame hanging ears. The screws are M6 * 12 pan head screws.

HD1U-4860G-FIFO Main box layout diagram (Front View)



1.3.1 Electric connection between the box and outside

1.3.1.1 Instruction

conn Sys Mode	AC Input	Battery and load output
HD1U-4860G-FIFO		 <p>LAOD+ LOAD- Common Neg terminal BAT+ Battery positive terminal BAT- Battery positive terminal</p> <p>Cable pressure fork terminal, connect as indicated, and tighten with a cross screwdriver.</p> <p>Above cable recommended for 4 square cable connection</p>

Notice :

1、 The AC input line is a high-voltage working line, and the operation process must ensure that the AC input is powered off. Temporary prohibition signs should be added to switches that are not allowed to be used during the operation process.

2、 The contact points of AC line terminals and other unnecessary exposed areas

should be fully insulated.

3、 Before powering on, it must be grounded.

1.3.1.2 Communication Connection Description

The communication line interface RS485 embedded in the system is located on the front panel of the monitoring module, and RS485 is the communication port used for communication with the upper computer.

*** RS485 Communication:**

A、 Connect one end of the communication line to RS485 on the front panel of the monitoring module.

B、 Connect the other end of the communication line to the RS485 of the upper computer, and the positive and negative terminals of RS485 correspond to the positive and negative terminals of RS485, respectively.

1.3.2 Installation inspection

(1) Installation inspection content: Stability inspection of frame installation, stability inspection of each assembly unit.

(2) Communication introduction and power distribution inspection: whether the chromatography of AC wires is standardized, whether the original wiring of the rack is loose, and whether the safety signs of the AC power distribution part are complete. Refer to the design data to check the communication wiring and wiring situation.


(3) DC output and battery connection points, numbering, polarity check of wire sequence, stability check of cable connection points, correctness and reliability check of busbar connection, and re inspection of battery connection polarity and sequence.

(4) All switches are placed in the off position.

1.4 Installation instructions for monitoring module and rectification module



Schematic diagram of module installation position (side)



Installation diagram of monitoring module (front)



Installation diagram of rectifier module (front)

The panels of the monitoring module and rectifier module both have handles. When inserting them into the main unit box, one hand should hold the handle tightly, the other hand should support the components, and slowly push them into the corresponding slots until the connection terminals of the rear panel of the components are inserted into the corresponding sockets of the main unit box system motherboard. Finally, tighten the fixing screws on the panel to the main unit box, and the installation is completed; When removing each component from the main unit box, first loosen the fixing screws on the panel, grip the handle, and slowly remove the component from the corresponding slot. Except for the modules embedded in the 3U-4890 system which are installed vertically, the rest are installed horizontally.

Note: The module has a hot swappable function, but before inserting the module, it is necessary to ensure that all the indicator lights on the module panel are off.

Chapter 2 Monitor Module

2.1 Appearance

Monitor G

GMonitor Appearance:




Dimension: 213.4mm x84mmx41.6mm

Weight: ≤0.6Kg

2.2 System composition

The G monitoring module, rectifier module, distribution box (or distribution cabinet) and other equipment form a communication power monitoring system. The system monitoring solution is shown in the figure:



2.3. Function

2.3.1 Communication function between monitoring unit and host computer

Communication with the host computer is an important feature of the G monitoring module. The

monitoring module provides an RS485 interface to the host computer, with the main functions of:

- (1) Send real-time simulation data of the monitoring unit to the host computer;
- (2) Send real-time switch data of the monitoring unit to the host computer;
- (3) Accept commands such as setting system parameters on the host computer and turning on/off the rectifier module;
- (4) Accept control commands sent by the host computer;
- (5) Send an alarm status to the upper computer.

The device and monitoring module have a host-slave relationship, and all reading, setting, and control processes should be initiated by the host computer. The monitoring module is always in a slave state, and without correct commands from the host computer, the monitoring module cannot actively report data to the host computer.

The analog data sent by the monitoring module to the host computer includes AC voltage, busbar voltage, battery current, load current, battery temperature, ambient temperature, ambient humidity, and module fan speed.

The switch signals sent by the monitoring module to the host computer include: module failure, DC undervoltage, DC overvoltage, battery power-off, module on/off, battery fuse status, load fuse status, battery float charging status, and backup sensor status.

The alarm status sent by the monitoring module to the upper computer includes AC overvoltage, AC undervoltage, AC phase loss, AC air switch, module fault, fan fault, module current limiting, DC undervoltage, DC overvoltage, battery power-off, load fuse, and battery fuse status.

The setting parameters sent by the host computer to the monitoring module include: average charging voltage, float charging voltage, DC output overvoltage alarm point, load current too high alarm point, battery current too high alarm point, battery undervoltage alarm point, battery temperature too low alarm point, battery temperature too high alarm point, environmental temperature too high alarm point, environmental temperature too low alarm point, primary power off voltage value, primary power off recovery value, battery power off alarm point, battery capacity, battery current limiting coefficient, temperature compensation coefficient, average charging to float charging current coefficient, float charging to average charging current coefficient, periodic average charging interval time, continuous average charging time, current limiting point current, AC voltage too high alarm point, AC voltage too low alarm point, AC power off value.

The control commands sent by the host computer to the monitoring module include: module on/off, temperature compensation on/off, backup relay on/off, and manual equalization.

2.3.2 Control function

The monitoring module can provide control signals based on certain monitored values or commands from the upper computer.

(1) Adjust output voltage: Adjust the average float charging voltage through backend software, and determine the system output voltage based on the system's average float charging status.

(2) Batt Management

Battery low voltage: When the output voltage is below the set battery low voltage, the system will output an alarm in the background and dry contact output an alarm.

Battery discharge: When the output voltage of the system is lower than the set battery discharge

voltage in the battery discharge state, the DC contactor of the battery will disconnect, close all loads, and disconnect the battery from the system. The whole machine will not work and needs to be powered on again to start.

Battery float charging management: When the charging current of the battery is greater than the set maximum charging current, the system performs constant current equalization charging on the battery. When the constant current equalization reaches the equalization charging voltage, the system performs constant voltage equalization charging. When the constant voltage equalization charging current is below the equalization to float charging current, the current floats. When the float charging current is greater than the equalization to float charging current, the system automatically switches to equalization charging when the equalization and float charging continue for a set time, If the constant pressure equalization time exceeds the set equalization duration, it will automatically switch to float charging, while manual equalization will switch to equalization charging.

Temperature compensation: When the battery temperature sensor is connected and temperature compensation is turned on, if the battery temperature is higher than 25 °C, temperature compensation will be applied. If it is lower than 25 °C, negative temperature compensation will be applied. The maximum compensation value will not exceed 2V, and the compensation value is equal to temperature × Coefficient.

2.3.3 Inspection function

The monitoring module can inspect the rectifier module and DC output.

- (1) The monitoring module can monitor whether the rectifier module is turned on/off, as well as the module's output voltage, current, fan speed, and fault status.
- (2) DC output - monitors the bus voltage, load current, battery current, temperature, and fuse status.

2.3.4 Remote control

Character table

Parameter	Description
Rectifier switch	Module controls the rectifier module to shut down according to the background power down command, and the module works automatically after power on
Rectifier Boost charge and float charge	Monitor shall control the charging and floating of the module according to the background command or battery management conditions
Rectifier Voltage Adjust	Monitor controls the module to adjust the voltage according to the background command or battery management conditions
Rectifier Current Limitation	Monitor controls the current limit of the module according to the battery management conditions
Six channel alarm output (dry node output)	They are system emergency alarm (AC power failure alarm, rectifier module alarm, LVD disengagement alarm), system non emergency alarm (AC overvoltage and undervoltage alarm, DC overvoltage and undervoltage alarm, 4-way load fusing alarm, 1-way battery fusing alarm, battery undervoltage alarm), high and low temperature alarm, door prohibition alarm, smoke alarm and water prohibition alarm. Among them, the system emergency alarm and non emergency alarm can be set

Remote Communication Table

Parameter	Description
Without AC Input	Alarm when the mains voltage is less than 60V and recover when it is greater than 70V
AC Input Volt Over	1) If it is greater than the AC overvoltage alarm point, the default alarm point is 295v; 2) Alarm recovery conditions: for 10 consecutive seconds, the listed electric voltage is less than overvoltage alarm point - 10V; Or continuously for 10 ± 3 minutes with the listed electric voltage < overvoltage alarm point - 3V 3) The overvoltage alarm point can be set in the background, and the mains overvoltage alarm can be shielded without mains power
AC Input Volt Under	1) It is less than AC undervoltage alarm point, and the default alarm point is 90V. 2) Alarm recovery conditions: for 10 seconds, the listed electric voltage > undervoltage alarm point + 10V; Or continuously for 10 ± 3 minutes with the listed electric voltage > undervoltage alarm point + 3V 3) The undervoltage alarm point can be set in the background, and the undervoltage alarm of mains power is shielded without time
DC output Volt Over	1) Alarm point setting, setting range (floating charge voltage + 1) - 60V, alarm return difference 1V; 2) Default value: 59V, DC overvoltage alarm when bus voltage > 59V, overvoltage alarm disappears when bus voltage ≤ 58V;
DC output Volt Under	1) The alarm point can be set, the lower limit voltage of the setting range is - (floating charge voltage - 2) V, and the alarm return difference is 1V; 2) Default value: 47v, DC undervoltage alarm when the bus voltage is less than 47v, and the undervoltage alarm disappears when the bus voltage is ≥ 48V;
Over Temp Alarm	If it is greater than the over temperature alarm point, the alarm recovery period is 3 °C, and the default alarm point is 50 °C
Low Temp Alarm	Less than the low temperature alarm point, the return difference of alarm recovery is 3 °C, and the default alarm point is - 10 °C
n#rectifier Fault	It indicates that n# rectifier module has at least one fault of input overvoltage and undervoltage, over temperature and output overvoltage
Battery Fuse break	when the battery circuit breaker is disconnected
Load Fuse break	when the load is air disconnected (L4 is connected to the fan, and its air disconnection does not generate an alarm)
Door	1 Channel
Fan Alarm	fan not working,
Smoke	

2.3.5 Others

2.5.1 LED

Name	Color	Status	Description
Running	Green	Light or not	Fault or without input
		Flick	OK
Alarming	Yellow	Not light	Without alarm
		Light	Alarm
Fault	Red	Not light	Without Fault
		Light	Fault

2.5.2 Connector Definition

2.5.2.1 RJ45



Name	Definition	Description
Ethernet		
RS485	PIN2	A+
	PIN3	B-



2.5.2.2 4*6P Connector

PIN1	PIN2	PIN3	PIN4	PIN5	PIN6
WATER		VCC		SMOKE	
DOOR		BAT-TEM2		LJ-TEM1	
DO01		DO02		DO03	
DO04		DO05		DO06	

2.3.6 Menu

2.3.6.1 LCD Operation

(1) VSM-G LCD Key:

There are only four operation keys "up, down, OK and cancel" on the front panel to carry out menus at all levels, function conversion, parameter setting, etc.

- a. Up - Flip up key: flip up the menu, change parameter setting, value increase and other operations;
- b. OK - Pan key: transfer to the same level and level menus;
- c. Down - scroll down key: flip down the menu to change parameter setting, value reduction and other operations;
- d. Cancel - cancel key: Cancel and return to the superior menu.

Move the time scale in the numerical parameter editing status, and long press to cancel the parameter modification.

(2) Main Menu:

a. Main page - display the basic information of the system immediately after the system is connected to the battery or rectifier module;

b. No matter what operation or display state, return to the main interface after stagnating for 30s.

(3)Hierarchy of monitoring menu structure: hierarchical, multi-level, step-by-step and cyclic tree structure (see menu structure for details).

2.3.6.2 Menu Structure

Main Menu	First Level
Standby System status, Exchange of information, Battery information, Tempe information	AC distribution
	DC distribution
	Rectifier module
	Alarm setting
	Shunt metering
	system configuration
	Event record
	Equipment information

2.3.6.3 AC distribution

First	Second	Third	
AC distribution	Status	A Phase Volt	
		A Phase Curr	
		B Phase Volt	
		B Phase Curr	
		C Phase Volt	
		C Phase Curr	
		Frequency	
		Power Factor	
		Active power	
		Active kWh	
		Alarm	A Phase Lost
			A Phase Volt Over
			A Phase Volt Under
	A Phase Curr Over		
	B Phase Lost		
	B phase Volt Over		
	B Phase Volt Under		
	B Phase Curr Over		
	C Phase Lost		
	C Phase Volt Over		
	C Phase Volt Under		
	C Phase Curr Over		
	Frequency Over		
	Frequency Under		

	Set	AC volt over alarm
		AC volt under alarm
		Phase lost alarm
		AC curr over alarm
		Frequency Over alarm
		Frequency Under alarm
	Configuration	CT
		Type
	calibration	A Phase Volt
		A Phase Curr
		B Phase Volt
		B Phase Curr
		C Phase Volt
		C Phase Curr

2.3.6.3 DC distribution

First	Second	Third	Fourth	
DC distribution	Status	Charge discharge status		
		Bus Volt		
		Load Volt		
		Batt Curr 1		
		Batt Curr 2		
		Rectifier total curr		
		Load total curr		
		Batt Temp		
		Circumstance Temp		
		Circumstance Humidity		
		Extending Temp		
		Batt Remain Capacity		
		Load Curr 1		
		Load Curr 2		
	Load Curr 3			
	Load Curr 4			
	Set	Charge Setting	Float Volt	
			Boost Volt	
			System lowest Volt	
			Batt Capacity	
Boost charge to float charge coefficient				
float charge to Boost charge coefficient				
Batt Charge Curr limit value				

		Alarm threshold Value	Sys Curr limit value
			LoadCurr over value
			Batt Curr over value
			DC volt over value
			Batt volt under value
		LVD set	LVD1 start
			Power down delay Load 1
			Power off Load 1
			Power recover Load 1
			Power down delay Load 2
			Power off Load 2
			Power recover Load 2
			Power down delay Load 3
			Power off Load 3
			Power recover Load 3
			Power down delay Load 4
			Power off Load 4
			Power recover Load 4
			LVD2 start
		LVD2 break value	
		LVD2 recover value	
		Temp&Humidity	Batt temp over alarm
			Batt temp low alarm
			Circumstance Temp Over
			Circumstance Temp under
			Circumstance Humi Over
			Circumstance Humi low
		Temp Compensation	Start
			coefficient
		Periodic Boost Charge	Start
			Interval time
			Duration time
		Manual Boost charge	time
			Charge time
		Batt quick charge	Start
			quick charge volt value
quick charge time limit			
Batt test	Start		
	Batt test starting voltage		
	Batt test ending voltage		
	Batt test Duration time		

		Test Result	
Alarm	DC Volt Over		
	DC Volt Under		
	Primary Power down		
	Secondary Power down		
	Load Fuse		
	Batt Fuse		
	Batt Curr over		
	Load Curr over limit		
	Batt Temp Over		
	Batt Temp Under		
	Lighting		
	Smoke		
	Water immersing		
	Door		
	Air Condition		
	Impact		
	Circumstance Temp Over		
	Circumstance Temp Under		
	Power Down Load 1		
	Power Down Load 2		
	Power Down Load 3		
	Power Down Load 4		
	Config	Number of Batt Set	
		Type of Batt Contactor	
		Batt Shunt Current	
		Batt Shunt Volt	
		Number of Load	
		Type of Load Contactor	
		Load Shunt Curren	
		Load Shunt Volt	
	Calibration	Bus Volt	
		Load Volt	
		Batt curr 1	
Batt curr 2			
Load total Curr			
Load Curr 1			
Load Curr 2			
Load Curr 3			
Load Curr 4			

2.3.6.4 Rectifier

First	Second	Third
Rectifier	Status	
	Curr/Volt Limit	Over Curr Limit value
		Over Volt limit value
	Energy saving settings	Energy saving start-up
		Module sleep coefficient
Number of rectifier	Rated Number of rectifier	

2.3.6.5 Alarm Setting

First	Second	Third
Alarm Setting	Relay status	DO1 Output status
		DO2 Output status
		DO3 Output status
		DO4 Output status
		DO5 Output status
		DO6 Output status
	Relay setting	DO1 Alarm Type
		DO1 Output Type
		DO2 Alarm Type
		DO2 Output Type
		DO3 Alarm Type
		DO3 Output Type
		DO4 Alarm Type
		DO4 Output Type
		DO5 Alarm Type
		DO5 Output Type
		DO6 Alarm Type
		DO6 Output Type
	Alarm Level	AC over volt alarm
		AC power off alarm
		AC frequency
		AC Over Curr
		AC MCB
		Rectifier
		Rectifier Over Volt
		Batt Under Volt
		LVD1 Alarm
		LVD2 Alarm
		Batt Over Curr
		Load Over Curr

	DI set	D11(Door)
		D12(Smoke)
		D13(Lighting)
		D14(Water immersion)
		D15(Air condition)
		D16(Impact)

2.3.6.6 Shunt Metering

First	Second
Shunt metering	Total Power consumption
	Monthly power consumption
	Daily power consumption
	Clean

2.3.6.7 system configuration

First	Second	Third
system configuration	Serial port settings	Equipment Address
		RS485 Baud rate
	network configuration	Local IP address
		Subnet mask
		Default gateway
		Port No
	Sys Display	Buzzer switch
		LCD Language
		LCD Backlight delay
	Sys time	
	Code set	

2.3.6.8 Event record

First	Second	Third
Event record	View records	Record 1
	
	Clean Records	

2.3.6.8 Equipment information

First	Second
Equipment information	

2.4. Installation

When the monitoring module is applied to the embedded power system, its installation is very simple. Push the monitoring module along the guide slot of the corresponding cabin of the main box of the power system, insert the pin of the monitoring module into the socket of the system motherboard, and tighten the screw on the front panel of the monitoring module to fix the monitoring module on the

main box of the system, so as to complete the mechanical fixation and electrical connection of the monitoring module.

2.5. Maintenance

(1) Cause analysis and maintenance of 485 communication interruption

① Check whether the 485 communication line is connected correctly and firmly.

② Detect the communication parameters (communication address and baud rate) between the monitoring unit and the host computer.

(2) If the reported data is incorrect (including analog quantity and switching quantity) and remains unchanged, or the control state is inconsistent with the issued command, or the parameter setting is inconsistent with the actual implementation, the following reasons may be caused:

※ the input signal is incorrect; ※ Input circuit is damaged; ※ Rectifier module failure.

Maintenance: contact the manufacturer for repair or replacement.

Chapter 3 Rectifier

3.1 Appearance

※Currently, our company uses rectifier modules in embedded systems, including 4830B, 4820B, 4815B, 4810B,

The Appearance of Rectifier is refe of right pic

Dimmension: 220mm*87mm*41.6mm

Weight: ≤1.2Kg



3.2 Technical specifications

3.2.1 Characters

Input and output				
Type Sys Mode	Input range	Input current max	DC Output rated current	Output power max
4810B	90-280Vac	3.7A	10A	600W
4815B	90-280Vac	5.6A	15A	800W
4820B	90-280Vac	7.5A	20A	1200W
4830B	90-280Vac	10A	30A	1800W

3.2.2 Protection function

Items	Unit	Yes/No	Min	Typical	Max	Recovery type
In Over volt prot	Vac	Yes	285	295		Auto recovery
In Over-volt prot Rey	Vac	Yes	280			Less than 5V
In under-Volt Protection	Vac	Yes			85	Auto recovery
In under-Volt Prot recov point	Vac	Yes			90	Less than 5V
Out over volt protection point	Vdc	Yes	58.5	59	61.5	Locked
Out current liminting poiot	A	Yes	Ia *110 %	Ia *115%	Ia *120 %	Auto recovery
short	A	Yes	Can be short circuited for a long time; After detecting a short circuit, hiccups work and can self recovery			
Over temp prot		Yes	can automatically recover at an ambient temperature of 65 °C			

Fan Fault prot		Yes	When all fans fail, the module reports a fan failure alarm and directly turns off the output;
----------------	--	-----	---

3.3 Requirements for the working environment

- (1) Working temp: $-33^{\circ}\text{C} \sim +55^{\circ}\text{C}$ (Can operate normally under full load conditions at an ambient temperature of $55^{\circ}\text{C} +55 \sim +65^{\circ}\text{C}$ Linear Derating $2.0\%/^{\circ}\text{C}$)
- (2) Humidity: $5 \sim 95\%$ (Non condensing)
- (3) Storage temp: $-40^{\circ}\text{C} \sim +70^{\circ}\text{C}$
- (4) Altitude: $0 \sim 3000\text{m}$
- (5) Air pressure: $70 \sim 106\text{KPa}$
- (6) Cooling function: Air forced cooling by fan

3.4 Instruction and maintenance

3.4.1 Panel



- 1. Fixing Screw 2. Fan 3. RUN running led(green)
- 4. ALARM led(yellow) 5. FAULT led(red)

3.4.2 Alarm signal indication

3.4.2.1 When the power module is running normally, the green light will be on; Otherwise, it will be extinguished. (Green light goes off when there is a power failure or no output from the module)

3.4.2.2 When the power module is running normally, the yellow light goes out; When the power module experiences abnormal temperature warning, automatic derating, current limiting, fan warning, and yellow light on.

3.4.2.3 When the power module is running normally, the red light goes off; When the power module malfunctions and there is no output due to overvoltage shutdown, fan failure, overheating shutdown, remote shutdown, or other internal reasons, the red light will be on.

LED				
LED Status	Module alarm status			
	Color	Normal;	Abnormal	abnormal cause
Run	Green	Lighting	light off	light off when a red light is on When the yellow light is on, see the table below
Protection	yellow	light off	Lighting	When the power module has recoverable protection and the module is activated, it will always light up. Otherwise, the yellow light will flash when communication is interrupted; OTP (when the ambient temperature exceeds 65 °C and the module shuts down due to overheating), input overvoltage and undervoltage are effective, and alarm is effective during overcurrent. Hibernation shutdown (When hibernation shutdown occurs, the module only lights up the protection indicator light and does not report an alarm)
Fault	Red	light off	Lighting	There is an irreparable fault inside the module, and the module FAIL is always on when it is valid. When PS enable is normal, the FAIL is valid when Vo-OV, fan failure (single or dual fan failure), output short circuit, or no output occurs.

3.4.3 Precautions for the use and maintenance of rectifier modules

- (1) If the red light (FAIL) on the front panel of the rectifier module remains on during normal operation, it indicates that the rectifier module has malfunctioned and needs to be removed from the system for repair. If the rectifier module is damaged, please contact the manufacturer. Without permission, non professionals from our factory are prohibited from disassembling the rectifier module.
- (2) Allow for hot swapping
 - a. When the entire module needs to be removed from operation, loosen the fastening screws, hold the handle, and pull it out without turning off the AC power. This can effectively ensure that a power system composed of multiple modules does not need to be powered off when a rectifier module needs to be removed for maintenance, ensuring the normal operation of the power system.
 - b. When connecting the electrical interface of the rectifier module to the power system, it is necessary to ensure that the indicator light on the front panel of the rectifier module is off before inserting the rectifier module.

Chapter 4 Safety precautions for use

1、Unpacking

Check if the equipment has been damaged during transportation. Keep the packaging materials until all module units of the power supply equipment have been registered and inspected.

2、General rule

- The air passage of the unit should not be obstructed.
- The distance between any conductive part of the power supply equipment and the metal components must comply with relevant safety standards.

3、Security protection measures

- Once the safety protection of the equipment is damaged, the equipment must stop working and refer to relevant maintenance regulations for handling.
- When the power supply equipment switches from a cold environment to a warm environment, condensation may cause dangerous problems, so grounding requirements must be strictly enforced. Qualified personnel are required to connect the equipment to the power supply.
- The power supply must be shut down for four minutes to allow sufficient discharge time for the capacitor before maintenance can be carried out on the power equipment.
- Do not operate in environments with volatile gases or flammable substances.
- Under no circumstances should the outer cover be removed or internal parts be touched.
- For safety reasons, do not perform internal maintenance or parts replacement separately.

In any case, such as operation, cleaning, or maintenance, please comply with the safety regulations specified above. If any violation causes safety concerns beyond the original design or manufacturing, our company will not be responsible.

4、Notice

- The power supply should be used under the environmental conditions specified in the manual;
- When using, the power supply should maintain good ventilation and heat dissipation; If smoke or unpleasant odor is found during startup or use, the power should be immediately turned off.

Chapter 5 Packaging, Transportation, and Storage

1、Packing:

The packaging box contains the product name, model, manufacturer identification, inspection certificate from the manufacturer's quality department, manufacturing date, etc; There is a product specification book and an attachment list inside the packaging box.

2、Transportation:

Suitable for transportation by car, ship, and plane. During transportation, it should be covered with canopy, sun protection, and civilized loading and unloading.

3、Storage:

When the product is not in use, it should be placed in the packaging box. The warehouse environment temperature is $-40\sim+80\text{ }^{\circ}\text{C}$, and the relative humidity is 10%~90%. The warehouse should not contain harmful gases, flammable, explosive products, or corrosive chemical products, and there should be no strong mechanical vibration, impact, or strong

magnetic field effects. The packaging box should be placed at least 20cm above the ground and at least 50cm away from walls, heat sources, and window type air inlets. The storage period under these specified conditions is generally 2 years, and after more than two years, it should be re inspected.

Chapter 6 Warranty

1、Warranty period

During the warranty period of one year, any natural damage caused by normal use of this product will be repaired free of charge by our company. However, any of the following situations are not covered by the warranty::

- Damage caused by unauthorized repair without the permission of our company.
- Any addition or modification.
- Incorrect operation or use.
- Abnormal environmental conditions exceeding specifications, resulting in damage.
- Intentional destruction caused by human factors.
- Damage caused by uncontrollable natural disasters.

2、Maintenance scope

If the power supply system operates abnormally due to material and manufacturing technology errors during the warranty period, our company will provide free repair or replacement. Maintenance services will include various labor services and any necessary adjustments or replacement of parts.

Chapter 7 Relevant Standards Referenced

- GB2423.1-89 Basic Test Procedures for Electrical and Electronic Products, Standard Ad.
- GB2423.2-89 Basic Test Procedures for Electrical and Electronic Products, Test Bd.
- GB3873-83 General Technical Conditions for Packaging of Communication Equipment Products.
- Detailed rules for quality certification and inspection of high-frequency switching power supply equipment for communication.
- YD/T731-2008 high-frequency switching rectifier for communication.
- XT-005-95 General Technical Requirements for Power Supply Systems of Communication Bureaus (Stations) (Provisional Regulations).

Chapter 8 System working Principle Diagram

